

# **OWNER'S MANUAL**



# Split Air Conditioner Arctic Series





MODELS: CH-S09FTXLA

CH-S12FTXLA CH-S18FTXLA CH-S24FTXLA

For proper operation, please read and keep this manual carefully.

Designed by Cooper&Hunter International Corporation, Oregon, USA www.cooperandhunter.com

# Content

# **Operation Notices**

Precautions.	1
Parts Name.	6
ScreenOperation Guide	
Buttons on remote controller	8
Introduction for icons on display screen	8
Introduction for buttons on remote controller	9
Replacement of batteries in remote controller	12
Emergency operation	13
Maintenance	
Clean and Maintenance	14
Malfunction	
Malfunction analysis	16
Installation Notice	
Installation dimension diagram	20
Tools for installation	21
Selection of installation location	21
Requirements for electric connection	22
Installation	
Installation of indoor unit	23
Installation of outdoor unit	31
Check after installation	35
Test and operation	
Test operation.	35
Attachment	
Configuration of connection pipe	35
Pipe expanding method	38

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

R410A(R32/125: 50/50): 1975



# **Operation and Maintenance**

- •This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- •Cleaning and user maintenance shall not be made by children without supervision.
- •Do not connect air conditioner to multi-purpose socket. Otherwise, it may cause fire hazard.
- Do disconnect power supply when cleaning air conditioner. Otherwise, it may cause electric shock.
- •If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- •Do not wash the air conditioner with water to avoid electric shock.
- •Do not spray water on indoor unit. It may cause electric shock or malfunction.
- After removing the filter, do not touch fins to avoid injury.
- •Do not use fire or hair dryer to dry the filter to avoid deformation or fire hazard.

# **№** WARNING

- Maintenance must be performed by qualified professionals. Otherwise, it may cause personal injury or damage.
- Do not repair air conditioner by yourself. It may cause electric shock or damage. Please contact dealer when you need to repair air conditioner.
- Do not extend fingers or objects into air inlet or air outlet. It may cause personal injury or damage.
- Do not block air outlet or air inlet. It may cause malfunction.
- Do not spill water on the remote controller, otherwise the remote controller may be broken.
- When below phenomenon occurs, please turn off air conditioner and disconnect power immediately, and then contact the dealer or qualified professionals for service.
  - Power cord is overheating or damaged.
  - There's abnormal sound during operation.
  - Circuit break trips off frequently.
  - Air conditioner gives off burning smell.
  - Indoor unit is leaking.
- If the air conditioner operates under abnormal conditions, it may cause malfunction, electric shock or fire hazard.
- When turning on or turning off the unit by emergency operation switch, please press this switch with an insulating object other than metal.
- Do not step on top panel of outdoor unit, or put heavy objects. It may cause damage or personal injury.



# **Attachment**

- •Installation must be performed by qualified professionals. Otherwise, it may cause personal injury or damage.
- Must follow the electric safety regulations when installing the unit.
- According to the local safety regulations, use qualified power supply circuit and circuit break.
- Do install the circuit break. If not, it may cause malfunction.
- An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.
- Including an circuit break with suitable capacity, please note the following table. Air switch should be included magnet buckle and heating buckle function, it can protect the circuit-short and overload.
- Air Conditioner should be properly grounded. Incorrect grounding may cause electric shock.
- Don't use unqualified power cord.
- Make sure the power supply matches with the requirement of air conditioner. Unstable power supply or incorrect wiring or malfunction. Please install proper power supply cables before using the air conditioner.
- Properly connect the live wire, neutral wire and grounding wire of power socket.
- Be sure to cut off the power supply before proceeding any work related to electricity and safety.



- Do not put through the power before finishing installation.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.
- The appliance shall be installed in accordance with national wiring regulations.
- Installation must be performed in accordance with the requirement of NEC and CEC by authorized personnel only.
- The air conditioner is the first class electric appliance. It
  must be properly grounding with specialized grounding
  device by a professional. Please make sure it is always
  grounded effectively, otherwise it may cause electric shock.
- The yellow-green wire in air conditioner is grounding wire, which can't be used for other purposes.
- The grounding resistance should comply with national electric safety regulations.
- The appliance must be positioned so that the plug is accessible.
- All wires of indoor unit and outdoor unit should be connected by a professional.
- If the length of power connection wire is insufficient, please contact the supplier for a new one. Avoid extending the wire by yourself.

# **Precautions**



- For the air conditioner with plug , the plug should be reachable after finishing installation.
- For the air conditioner without plug, an circuit break must be installed in the line.
- If you need to relocate the air conditioner to another place, only the qualified person can perform the work.
   Otherwise, it may cause personal injury or damage.
- Select a location which is out of reach for children and far away from animals or plants. If it is unavoidable, please add the fence for safety purpose.
- The indoor unit should be installed close to the wall.


### Working temperature range

	Indoor side DB/WB(°C)	Outdoor side DB/WB(°C)
Maximum cooling	32/23	43/26
Maximum heating	27/-	24/18

### **NOTICE:**

• The operating temperature range (outdoor temperature) for cooling is -15  $^{\circ}$  ~43  $^{\circ}$ ; Heating temperature range is -25  $^{\circ}$  ~24  $^{\circ}$ .

# **Parts Name**




### **NOTICE:**

Actual product may be different from above graphics, please refer to actual products.


# **Parts Name**

# Display


### For some model:




#### For some model:



#### For some model:



#### For some model:



Display content or position may be different from above graphics, please refer to actual products.

# **Buttons on remote controller**



### 1 ON/OFF

Press it to start or stop operation.

- : Press it to decrease temperature setting.
- + : Press it to increase temperature setting.

### 4 MODE

Press it to select operation mode (AUTO/COOL/DRY/FAN/HEAT).

5 FAN

Press it to set fan speed.

6 SWING
Press it set swing angle.

- 7 | I FEEL
- 8 辛/紀
  Press it to set HEALTH or AIR function.
- 9 SLEEP
- 10 TEMP
- 11 CLOCK
  Press it set clock.
- 12 T-0N T-0FF
  Press it to set auto-off/auto-on timer.
- 13 TURBO
- 14 LIGHT Press it to turn on/off the light.
- 15 X-FAN

# Introduction for buttons on remote controller,

1 ON/OFF:

Press this button to turn on the unit . Press this button again to turn off the unit.

2 —

Press this button to decrease set temperature. Holding it down above 2 seconds rapidly decreases set temperature. In AUTO mode, set temperature is not adjustable.

3 + :

Press this button to increase set temperature. Holding it down above 2 seconds rapidly increases set temperature. In AUTO mode, set temperature is not adjustable.

4 MODE :

Each time you press this button,a mode is selected in a sequence that goes from AUTO, COOL,DRY, FAN,and HEAT \*, as the following:



\*Note:Only for models with heating function.

After energization, AUTO mode is defaulted. In AUTO mode, the set temperature will not be displayed on the LCD, and the unit will automatically select the suitable operation mode in accordance with the room temperature to make indoor room comfortable.

5 FAN:

This button is used for setting Fan Speed in the sequence that goes from AUTO, \_\_\_\_,

to \_\_\_\_, then back to Auto.



Medium-High speed High speed

6 SWING:

Press this button to set up &down swing angle, which circularly changes as below:

This remote controller is universal . If any command  $\stackrel{>}{=}$  ,  $\stackrel{>}{=}$  or  $\stackrel{=}{=}$  is sent out, the unit will carry out the command as  $\stackrel{>}{=}$ 

indicates the guide louver swings as:

\\ + \\ + -\\-\-\-\-\\

7 I FEEL:

Press this button to turn on I FEEL function. The unit automatically adjust temperature according to the sensed temperature. Press this button again to cancel I FEEL function.

# Introduction for buttons on remote controller

# 8 2/2

Press this button to achieve the on and off of healthy and scavenging functions in operation status. Press this button for the first time to start scavenging function; LCD displays "\( \\_ \)". Press the button for the second time to start healthy and scavenging functions simultaneously; LCD displays "\( \\_ \)" and "\( \\_ \)". Press this button for the third time to quit healthy and scavenging functions simultaneously. Press the button for the fourth time to start healthy function; LCD display "\( \\_ \)". Press this button again to repeat the operation above.

### 9 SLEEP:

- Press this button, can select Sleep 1 ( 1 ), Sleep 2 ( 2 ), Sleep 3 ( 3 ) and cancel the Sleep, circulate between these, after electrified, Sleep Cancel is defaulted.
- Sleep 1 is Sleep mode 1, in Cool, Dehumidify modes: sleep status after run for one hour, the
  main unit setting temperature will increase 1 °C, setting temperature increased 2°C, the unit will
  run at this setting temperature; In Heat mode: sleep status after run for one hour, the setting
  temperature will decrease 1 °C, 2 hours, setting temperature will decrease 2 °C, then the unit
  will run at this setting temperature.
- Sleep 2 is sleep mode 2, that is air conditioner will run according to the presetting a group of sleep temperature curve.
- Sleep 3- the sleep curve setting under Sleep mode by DIY:
  - (1) Under Sleep 3 mode, press "Turbo" button for a long time, remote control enters into user individuation sleep setting status, at this time, the time of remote control will display "1hour ", the setting temperature "88" will display the corresponding temperature of last setting sleep curve and blink (The first entering will display according to the initial curve setting value of original factory);
  - (2) Adjust "+" and "-" button, could change the corresponding setting temperature, after adjusted, press "Trubo "button for confirmation;
  - (3) At this time, 1hour will be automatically increased at the timer postion on the remote control, (that are "2hours" or "3hours" or "8hours"), the place of setting temperature "88" will display the corresponding temperature of last setting sleep curve and blink;
  - (4) Repeat the above step (2)  $\sim$  (3) operation, until 8hours temperature setting finished, sleep, curve setting finished, at this time, the remote control will resume the original timer display; temperature display will resume to original setting temperature.
- Sleep3- the sleep curve setting under Sleep mode by DIY could be inquired: The user could accord to sleep curve setting method to inquire the presetting sleep curve, enter into user individuation sleep setting status, but do not change the temperature, press "Turbo" button directly for confirmation. Note: In the above presetting or enquiry procedure, if continuously within10s, there is no button pressed, the sleep curve setting within 10s, there is no button pressed, the sleep curve setting status will be automatically quit and resume to display the original displaying. In the presetting or enquiry procedure, press "ON/OFF" button, "Mode" button, "Timer"button or "Sleep" button, the sleep curve setting or enquiry status will quit similarly.

# Introduction for buttons on remote controller,

### 10 TEMP:

Press this button, could select displaying the indoor setting temperature or indoor ambient temperature. When the indoor unit firstly power on it will display the setting temperature, if the temperature's displaying status is changed from other status to " (a)", displays the ambient temperature, 3s later or within 3s, it receives other remote control signal that will return to display the setting temperature. if the users haven't set up the temperature displaying status, that will display the setting temperature.

### 11 CLOCK:

Press CLOCK button, blinking (4). Within 5 seconds, pressing +or - button adjusts the present time. Holding down either button above 2 seconds increases or decreases the time by 1 minute every 0.5 second and then by 10 minutes every 0.5 second. During blinking after setting, press CLOCK button again to confirm the setting, and then (4) will be constantly displayed.

### 12 T-0N T-0FF:

Press T-ON button to initiate the auto-ON timer. To cancel the auto-timer program, simply press this button again.

After press of this button, (J) disappears and "ON "blinks .00:00 is displayed for ON time setting. Within 5 seconds, press + or - button to adjust the time value. Every press of either button changes the time setting by 1 minute. Holding down either button rapidly changes the time setting by 1 minute and then 10 minutes. Within 5 Seconds after setting, press TIMER ON button to confirm.

Press T-OFF button to initiate the auto-off timer. To cancel the auto-timer program, simply press the button again.TIMER OFF setting is the same as TIMER ON.

### 13 TURBO:

Press this button to activate / deactivate the Turbo function which enables the unit to reach the preset temperature in the shortest time. In COOL mode, the unit will blow strong cooling air at super high fan speed. In HEAT mode, the unit will blow strong heating air at super high fan speed.

#### 14 LIGHT:

Press LIGHT button to turn on the display's light and press this button again to turn off the display's light. If the light is turned on , is displayed. If the light is turned off, disappears.

### 15 X-FAN:

Pressing X-FAN button in COOL or DRY mode, the icon is displayed and the indoor fan will continue operation for 2 minutes in order to dry the indoor unit even though you have turned off the unit.

After energization, X-FAN OFF is defaulted. X-FAN is not available in AUTO, FAN or HEAT mode.

# Introduction for buttons on remote controller

- Combination of "+" and "-" buttons: About lock

  Press "+ " and "-" buttons simultaneously to lock or unlock the keypad. If the remote controller is locked, is displayed. In this case, pressing any button, blinks three times.
- 17 Combination of "MODE" and "-" buttons: About switch between Fahrenheit and centigrade At unit OFF, press "MODE" and "-" buttons simultaneously to switch between  $^{\circ}$ C and  $^{\circ}$ F.
- Combination of "TEMP" and "CLOCK" buttons: About Energy-saving Function

  Press "TEMP" and "CLOCK" simultaneously in COOL mode to start energy-saving function.

  Nixie tube on the remote controller displays "SE". Repeat the operation to quit the function.
- 19 Combination of "TEMP" and "CLOCK" buttons: About 8°C Heating Function

  Press "TEMP" and "CLOCK" simultaneously in HEAT mode to start 8°C Heating Function

  Nixie tube on the remote controller displays "\$" and a selected temperature of "8°C".


  (46°F if Fahrenheit is adopted). Repeat the operation to guit the function.
- About Back-lighting Function
  The unit lights for 4s when energizing for the first time, and 3s for later press.

# Replacement of batteries in remote controller

- Remove the battery cover plate from the rear of the remote controller.
   (As shown in the figure)
- 2. Take out the old batteries.
- 3. Insert two new AAA1.5V dry batteries, and pay attention to the polarity.
- 4. Reinstall the battery cover plate.

#### ★ Notes:

- When replacing the batteries, do not use old or different types of batteries, otherwise, it may cause malfunction.
- If the remote controller will not be used for a long time, please remove batteries to prevent batteries from leaking.
- The operation should be performed in its receiving range.
- It should be kept 1m away from the TV set or stereo sound sets.
- If the remote controller does not operate normally, please take the batteries out and reinsert them after 30 seconds. If it still can't operate properly, replace the batteries.






Sketch map for replacing batteries

# **Emergency operation**

If remote controller is lost or damaged, please use auxiliary button to turn on or turn off the air conditioner. The operation in details are as below: As shown in the fig. Open panel, press aux. button to turn on or turn off the air conditioner. When the air conditioner is turned on, it will operate under auto mode.



# **⚠WARNING**:

Use insulated object to press the auto button

# Clean and maintenance

# **⚠** WARNING

- Turn off the air conditioner and disconnect the power before cleaning the air conditioner to avoid electric shock.
- Do not wash the air conditioner with water to avoid electric shock.
- Do not use volatile liquid to clean the air conditioner.

### Clean surface of indoor unit

When the surface of indoor unit is dirty, it is recommended to use a soft dry cloth or wet cloth to wipe it.

### **NOTICE:**

• Do not remove the panel when cleaning it.

# **Clean and Maintenance**

### Clean filter



# Open panel


Pull out the panel to a certain angle as shown in the fig.



3

# Clean filter


- Use dust catcher or water to clean the filter.
- When the filter is very dirty, use the water (below 45°C) to clean it, and then put it in a shady and cool place to dry.



2

### Remove filter

Remove the filter as indicated in the fig.





### Install filter

Install the filter and then close the panel cover tightly.



# **MARNING**

- The filter should be cleaned every three months. If there is much dust in the operation environment, clean frequency can be increased.
- After removing the filter, do not touch fins to avoid injury.
- Do not use fire or hair dryer to dry the filter to avoid deformation or fire hazard.

# **Clean and Maintenance**

# NOTICE: Checking before use-season

- 1. Check whether air inlets are blocked.
- 2. Check whether air switch, plug and socket are in good condition.
- 3. Check whether filter is clean.
- 4. Check whether drainage pipe is damaged.

# NOTICE: Checking after use-season

- 1. Disconnect power supply.
- 2. Clean filter and indoor unit's panel.

# **Notice for recovery**

- 1. Many packing materials are recyclable materials. Please dispose them in appropriate recycling unit.
- 2. If you want to dispose the air conditioner, please contact local dealer or consultant service center for the correct disposal method.

#### Note!

The manufacturer reserves the right to make modifications to the products without prior notice.

# Malfunction analysis

# **General phenomenon analysis**

Please check below items before asking for maintenance. If the malfunction still can't be eliminated, please contact local dealer or qualified professionals.

Phenomenon	Check items	Solution
	<ul> <li>Whether it's interfered severely (such as static electricity, stable voltage)?</li> </ul>	<ul> <li>Pull out the plug. Reinsert the plug after about 3min, and then turn on the unit again.</li> </ul>
	<ul> <li>Whether remote controller is within the signal receiving range?</li> </ul>	Signal receiving range is 8m.
Indoor unit	<ul><li>Whether there are obstacles?</li></ul>	Remove obstacles.
can't receive remote controller's	<ul> <li>Whether remote controller is pointing at the receiving window?</li> </ul>	<ul> <li>Select proper angle and point the remote controller at the re- ceiving window on indoor unit.</li> </ul>
signal or remote controller	<ul> <li>Is sensitivity of remote contro- ller low; fuzzy display and no display?</li> </ul>	<ul> <li>Check the batteries. If the power of batteries is too low, please replace them.</li> </ul>
action. • No disp	No display when operating remote controller?	<ul> <li>Check whether remote cont- roller appears to be damaged.</li> <li>If yes, replace it.</li> </ul>
	Fluorescent lamp in room?	Take the remote controller close to indoor unit.
		Turn off the fluoresent lamp and then try it again.
	<ul> <li>Air inlet or air outlet of indoor unit is blocked?</li> </ul>	Eliminate obstacles.
No air emitted from indoor	<ul> <li>Under heating mode, indoor temperature is reached to set temperature?</li> </ul>	<ul> <li>After reaching to set temper- ature, indoor unit will stop bl- owing out air.</li> </ul>
	<ul><li>Heating mode is turned on just now?</li></ul>	<ul> <li>In order to prevent blowing out cold air, indoor unit will be started after delaying for sev- eral minutes, which is a nor- mal phenomenon.</li> </ul>

# Malfunction analysis

Phenomenon	Check items	Solution
	Power failure?	Wait until power recovery.
	• Is plug loose?	Reinsert the plug.
	<ul><li>Air switch trips off or fuse is burnt out?</li></ul>	<ul> <li>Ask professional to replace air switch or fuse.</li> </ul>
Air condit- ioner can't	Wiring has malfunction?	Ask professional to replace it.
operate	<ul> <li>Unit has restarted immediately after stopping operation?</li> </ul>	Wait for 3min, and then turn on the unit again.
	<ul> <li>Whether the function setting for remote controller is correct?</li> </ul>	Reset the function.
Mist is emitted from indoor unit's air outlet	Indoor temperature and humidity is high?	Because indoor air is cooled rapidly. After a while, indoor temperature and humidity will be decrease and mist will disappear.
Set temperature can't	<ul> <li>Unit is operating under auto mode?</li> </ul>	Temperature can't be adjusted under auto mode.  Please switch the operation mode if you need to adjust temperature.
be adjusted	<ul> <li>Your required temperature exceeds the set temperature range?</li> </ul>	• Set temperature range: 16℃ ~30℃.
	Voltage is too low?	Wait until the voltage
Cooling (heating)		resumes normal.
	• Filter is dirty?	Clean the filter.
effect is not good.	<ul> <li>Set temperature is in proper range?</li> </ul>	<ul> <li>Adjust temperature to proper range.</li> </ul>
	Door and window are open?	Close door and window.

# Malfunction analysis/

Phenomenon	Check items	Solution
Odours are emitted	Whether there's odour source, such as furniture and cigarette, etc.	<ul><li> Eliminate the odour source.</li><li> Clean the filter.</li></ul>
Air conditioner operates abnormally suddenly	Whether there's interference, such as thunder, wireless devices, etc.	Disconnect power, put back power, and then turn on the unit again.
"Water flowing" noise	Air conditioner is turned on or turned off just now?	The noise is the sound of refrigerant flowing inside the unit, which is a normal phenomenon.
Cracking noise	Air conditioner is turned on or turned off just now?	This is the sound of friction caused by expansion and/or contraction of panel or other parts due to the change of temperature.

# Malfunction analysis

### **Error Code**

 When air conditioner status is abnormal, temperature indicator on indoor unit will blink to display corresponding error code. Please refer to below list for identification of error code.

Error code	Troubleshooting
E5	It can be eliminated after restarting the unit. If not , please contact qualified professionals for service.
E8	It can be eliminated after restarting the unit. If not,please contact qualified professionals for service.
U8	It can be eliminated after restarting the unit. If not,please contact qualified professionals for service.
H6	It can be eliminated after restarting the unit. If not,please contact qualified professionals for service.
C5	Please contact qualified professionals for service.
F1	Please contact qualified professionals for service.
F2	Please contact qualified professionals for service.


Note: If there're other error codes, please contact qualified professionals for service.



### WARNING

- When below phenomenon occurs, please turn off air conditioner and disconnect power immediately, and then contact the dealer or qualified professionals for service.
  - Power cord is overheating or damaged.
  - There's abnormal sound during operation.
  - Air switch trips off frequently.
  - Air conditioner gives off burning smell.
  - Indoor unit is leaking.
- Do not repair or refit the air conditioner by yourself.
- If the air conditioner operates under abnormal conditions, it may cause malfunction, electric shock or fire hazard.

# Installation dimension diagram



# **Tools for installation**

1 Level meter	2 Screw driver		3 Impact drill
4 Drill head	5 Pipe expander		6 Torque wrench
7 Open-end wrench	8 Pipe cutter		9 Leakage detector
10 Vacuum pump	11 Pressure meter		12 Universal meter
13 Inner hexagon spanner		14	Measuring tape

### Note:

- Please contact the local agent for installation.
- Don't use unqualified power cord.

# Selection of installation location

### Basic requirement

Installing the unit in the following places maycause malfunction. If it is unavoidable, please consult the local dealer:

- 1. The place with strong heat sources, vapors, flammable or explosive gas, or volatile objects spread in the air.
- 2. The place with high-frequency devices (such as welding machine, medical equipment).
- 3. The place near coast area.
- 4. The place with oil or fumes in the air.
- 5. The place with sulfureted gas.
- 6. Other places with special circumstances.
- 7. Do not use the unit in the immediate surroundings of a laundry a bath a shower or a swimming pool.

#### Indoor unit

- 1. There should be no obstruction near air inlet.
- 2. Select a location where the condensation water can be dispersed easily and won't affect other people.
- 3. Select a location which is convenient to connect the outdoor unit and near the power socket.
- 4. Select a location which is out of reach for children.
- 5. The location should be able to withstand the weight of indoor unit and won't increase noise and vibration.
- 6. The appliance must be installed 2.5m above floor.
- 7. Don't install the indoor unit right above the electric appliance.
- 8. Please try your best to keep way from fluorescent lamp.

# Requirements for electric connection

### Safety precaution

- 1. Must follow the electric safety regulations when installing the unit.
- 2. According to the local safety regulations, use qualified power supply circuit and air switch.
- 3. Make sure the power supply matches with the requirement of air conditioner. Unstable power supply or incorrect wiring or malfunction. Please install proper power supply cables before using the air conditioner.
- 4. Properly connect the live wire, neutral wire and grounding wire of power socket.
- 5. Be sure to cut off the power supply before proceeding any work related to electricity and safety.
- 6. Do not put through the power before finishing installation.
- 7. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 8. The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.
- 9. The appliance shall be installed in accordance with national wiring regulations.

# **Grounding requirement**

- 1. The air conditioner is the first class electric appliance. It must be properly grounding with specialized grounding device by a professional. Please make sure it is always grounded effectively, otherwise it may cause electric shock.
- 2. The yellow-green wire in air conditioner is grounding wire, which can't be used for other purposes.
- 3. The grounding resistance should comply with national electric safety regulations.
- 4. The appliance must be positioned so that the plug is accessible.
- 5. An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.

Step one: choosing installation location

Recommend the installation location to the client and then confirm it with the client.


### Step two: install wall-mounting frame

- 1. Hang the wall-mounting frame on the wall; adjust it in horizontal position with the level meter and then point out the screw fixing holes on the wall.
- 2. Drill the screw fixing holes on the wall with impact drill (the specification of drill head should be the same as the plastic expansion particle) and then fill the plastic expansion particles in the holes.
- 3. Fix the wall-mounting frame on the wall with tapping screws (ST4.2X25TA) and then check if the frame is firmly installed by pulling the frame. If the plastic expansion particle is loose, please drill another fixing hole nearby.


### Step three: open piping hole

Choose the position of piping hole according to the direction of outlet pipe. The
position of piping hole should be a little lower than the wall-mounted frame,
shown as below.


### 07、09K:




#### 18K:



### 12K:




#### 24K:



2. Open a piping hole with the diameter of Φ55 or Φ70 on the selected outlet pipe position. In order to drain smoothly, slant the piping hole on the wall slightly downward to the outdoor side with the gradient of 5-10°.


### Note:

- Pay attention to dust prevention and take relevant safety measures when opening the hole.
- The plastic expansion particles are not provided and should be bought locally.




### Step four: outlet pipe

 The pipe can be led out in the direction of right, rear right, left or rear left.




When select leading out the pipe from left or right, please cut off the corresponding hole on the bottom case.




### Step five: connect the pipe of indoor unit

- Aim the pipe joint at the corresponding bellmouth.
- 2. Pretightening the union nut with hand.




3. Adjust the torque force by referring to the following sheet. Place the open-end wrench on the pipe joint and place the torque wrench on the union nut. Tighten the union nut with torque wrench.




Hex nut diameter	Tightening torque (N·m)
Ф6	15~20
Ф 9.52	30~40
Ф 12	45~55
Ф 16	60~65
Ф 19	70~75


Wrap the indoor pipe and joint of connection pipe with insulating pipe, and then wrap it with tape.



# Step six: install drain hose


- Connect the drain hose to the outlet pipe of indoor unit.
- 2. Bind the joint with tape.






#### Note:

- Add insulating pipe in the indoor drain hose in order to prevent condensation.
- The plastic expansion particles are not provided.




### Step seven: connect wire of indoor unit


 Open the panel, remove the screw on the wiring cover and then take down the cover.



Make the power connection wire go through the cable-cross hole at the back of indoor unit and then pull it out from the front side.



 Remove the wire clip; connect the power connection wire to the wiring terminal according to the color; tighten the screw and then fix the power connection wire with wire clip.




- 4. Put wiring cover back and then tighten the screw.
- 5.Close the panel.

#### Note:


- All wires of indoor unit and outdoor unit should be connected by a professional.
- If the length of power connection wire is insufficient, please contact the supplier for a new one. Avoid extending the wire by yourself.
- For the air conditioner with plug, the plug should be reachable after finishing installation.
- For the air conditioner without plug, an air switch must be installed in the line. The air switch should be all-pole parting and the contact parting distance should be more than 3mm.

### Step eight: bind up pipe

1. Bind up the connection pipe, power cord and drain hose with the band.



 Reserve a certain length of drain hose and power cord for installation when binding them. When binding to a certain degree, separate the indoor power and then separate the drain hose.




- 3. Bind them evenly.
- 4. The liquid pipe and gas pipe should be bound separately at the end.


#### Note:

- The power cord and control wire can't be crossed or winding.
- The drain hose should be bound at the bottom.

# Step nine: hang the indoor unit

- 1. Put the bound pipes in the wall pipe and then make them pass through the wall hole.
- 2. Hang the indoor unit on the wall-mounting frame.
- 3. Stuff the gap between pipes and wall hole with sealing gum.
- 4. Fix the wall pipe.
- 5. Check if the indoor unit is installed firmly and closed to the wall.






#### Note:

• Do not bend the drain hose too excessively in order to prevent blocking.

# **Parts Name**




# A

### Notice:

Actual product may be different from above graphics, please refer to actual products.

# Installation dimension diagram/



### Tools for installation

1 Level meter	2 Screw driver		3 Impact drill
4 Drill head	5 Pipe exp	pander	6 Torque wrench
7 Open-end wrench	8 Pipe cutter		9 Leakage detector
10 Vacuum pump	11 Pressure meter		12 Universal meter
13 Inner hexagon spanner		14	Measuring tape

### Note:

- Please contact the local agent for installation.
- Don't use unqualified power cord.

### Selection of installation location

### Basic requirement

Installing the unit in the following places maycause malfunction. If it is unavoidable, please consult the localdealer:

- The place with strong heat sources, vapors, flammableor explosive gas, or volatile objects spread in the air.
- The place with high-frequency devices (such as welding machine, medical equipment).
- 3. The place near coast area.
- 4. The place with oil or fumes in the air.
- The place with sulfureted gas.
- Other places with special circumstances.
- 7. The appliance shall not be installed in the laundry.

#### Outdoor unit

- Select a location where the noise and outflow air emitted by the outdoor unit will not affect neighborhood.
- The location should be well ventilated and dry, in which the outdoor unit won't be exposed directly to sunlight or strong wind.
- 3. The location should be able to withstand the weight of outdoor unit.
- Make sure that the installation follows the requirement of installation dimension diagram.
- 5. Select a location which is out of reach for children and far away from animals or plants. If it is unavoidable, please add the fence for safety purpose.

### Requirements for electric connection,

### Safety precaution

- 1. Must follow the electric safety regulations when installing the unit.
- According to the local safety regulations, use qualified power supply circuit and air switch.
- 3. Make sure the power supply matches with the requirement of air conditioner. Unstable power supply or incorrect wiring or malfunction. Please install proper power supply cables before using the air conditioner.
- 4. Properly connect the live wire, neutral wire and grounding wire of power socket.
- Be sure to cut off the power supply before proceeding any work related to electricity and safety.
- 6. Do not put through the power before finishing installation.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.
- 9. The appliance shall be installed in accordance with national wiring regulations.

### **Grounding requirement**

- The air conditioner is the first class electric appliance. It must be properly
  grounding with specialized grounding device by a professional. Please make
  sure it is always grounded effectively, otherwise it may cause electric shock.
- The yellow-green wire in air conditioner is grounding wire, which can't be used for other purposes.
- 3. The grounding resistance should comply with national electric safety regulations.
- 4. The appliance must be positioned so that the plug is accessible.
- An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.
- Including an circuit break with suitable capacity, please note the following table.
   Air switch should be included magnet buckle and heating buckle function, it can protect the circuit-short and overload. (Caution: please do not use the fuse only for protect the circuit)


Air-conditioner	Circuit break capacity
09、12、18K	16A
24K	25A

# Step one: fix the support of outdoor unit (select it according to the actual installation situation)

- 1. Select installation location according to the house structure.
- 2. Fix the support of outdoor unit on the selected location with expansion screws.

#### Note:


- Take sufficient protective measures when installing the outdoor unit.
- Make sure the support can withstand at least four times of the unit weight.
- The outdoor unit should be installed at least 3cm above the floor in order to install drain joint.
- For the unit with cooling capacity of 2300W ~5000W, 6 expansion screws are needed; for the unit with cooling capacity of 6000W ~8000W, 8 expansion screws are needed; for the unit with cooling capacity of 10000W ~16000W, 10 expansion screws are needed.



at least 3cm above the floor


# Step two: install drain joint (Only for cooling and heating unit)

- Connect the outdoor drain joint into the hole on the chassis, as shown in the picture below.
- Connect the drain hose into the drain vent.



### Step three: fix outdoor unit


- Place the outdoor unit on the support.
- 2. Fix the foot holes of outdoor unit with bolts.




# Installation of outdoor unit,

### Step four: connect indoor and outdoor pipes


 Remove the screw on the right handle of outdoor unit and then remove the handle.



Remove the screw cap of valve and aim the pipe joint at the bellmouth of pipe.



Pretightening the union nut with hand.




 Tighten the union nut with torque wrench by referring to the sheet below.

Hex nut diameter	Tightening torque (N·m)
Ф6	15~20
Ф 9.52	30~40
Ф 12	45~55
Ф 16	60~65
Ф 19	70~75

# Step five: connect outdoor electric wire

 Remove the wire clip; connect the power connection wire and signal control wire (only for cooling and heating unit) to the wiring terminal according to the color; fix them with screws.




Fix the power connection wire and signal control wire with wire clip (only for cooling and heating unit).

#### Note:

- After tighten the screw, pull the power cord slightly to check if it is firm.
- Never cut the power connection wire to prolong or shorten the distance.

### Step six: neaten the pipes

- The pipes should be placed along the wall, bent reasonably and hidden possibly. Min. semidiameter of bending the pipe is 10cm.
- If the outdoor unit is higher than the wall hole, you must set a U-shaped curve in the pipe before pipe goes into the room, in order to prevent rain from getting into the room.





### Outdoor Condensate Drainage

During heating operation, the condensate and defrosting water should be drained out reliably through the drain hose. Install the outdoor drain connector in a  $\Phi25$  hole on the base plate and attach the drain hose to the connector so that the waste water formed in the outdoor unit can be drained out. The hole diameter 25 must be plugged. Whether to plug other holes will be determined by the dealers to actual conditions.

The 09K QB $_{\circ}$  12K QC $_{\circ}$  18K QD $_{\circ}$  24K QE UNIT drainage hole consists of two  $\Phi$ 25 and two kidney holes (see the fig.1). The drain plug consists of one  $\Phi$ 25 and two kidney plugs.

(The figures in this manual may be different with the material objects, please refer to the material objects for reference)






# Vacuum pumping

### Use vacuum pump

- Remove the valve caps on the liquid valve and gas valve and the nut of refrigerant charging vent.
- 2. Connect the charging hose refrigerant charging of piezometer to the refrigerant charging vent of gas nut of refrigerant valve and then connect the charging vent other charging hose to the vacuum pump.
- Open the piezometer completely and operate for 10-15min to check if the pressure of piezometer remains in -0.1MPa.
- Close the vacuum pump and maintain this status for 1-2min to check if the pressure of piezometer remains



Remove the piezometer, open the valve core of liquid valve and gas valve completely with inner hexagon spanner.

liquid valve

gas valve

piezometer

vacuum pump

valve cap

inner hexagon

spanner

- 6. Tighten the screw caps of valves and refrigerant charging vent.
- 7. Reinstall the handle.

# Leakage detection

- With leakage detector: Check if there is leakage with leakage detector.
- 2. With soap water:

If leakage detector is not available, please use soap water for leakage detection. Apply soap water at the suspected position and keep the soap water for more than 3min. If there are air bubbles coming out of this position, there's a leakage.

# Check after installation

• Check according to the following requirement after finishing installation.

Items to be checked	Possible malfunction
Has the unit been installed firmly?	The unit may drop, shake or emit noise
Have you done the refrigerant leakage test?	It may cause insufficient cooling (heating) capacity.
Is heat insulation of pipeline sufficient?	It may cause condensation and water dripping.
Is water drained well?	It may cause condensation and water dripping.
Is the voltage of power supply according to the voltage marked on the nameplate?	It may cause malfunction or damaging the parts.
Is electric wiring and pipeline installed correctly?	It may cause malfunction or damaging the parts.
Is the unit grounded securely?	It may cause electric leakage.
Does the power cord follow the specification?	It may cause malfunction or damaging the parts.
Is there any obstruction in the air inlet and outlet?	It may cause insufficient cooling (heating) capacity.
The dust and sundries caused during installation are removed?	It may cause malfunction or damaging the parts.
The gas valve and liquid valve of connection pipe are open completely?	It may cause insufficient cooling (heating) capacity.

# **Test operation**

### 1. Preparation of test operation

- The client approves the air conditioner.
- Specify the important notes for air conditioner to the client.

### 2. Method of test operation

- Put through the power, press ON/OFF button on the remote controller to start operation.
- Press MODE button to select AUTO, COOL, DRY, FAN and HEAT to check whether the operation is normal or not.
- $\bullet$  If the ambient temperature is lower than 16  $^\circ\!\mathbb{C}$  , the air conditioner can't start cooling.

# Configuration of connection pipe

- 1. Standard length of connection pipe
  - 5m, 7.5m, 8m.
- 2.Min. length of connection pipe is 3m.
- 3.Max. length of connection pipe and max. high difference.

Cooling capacity	Max length of connection pipe	Max height difference
5000Btu/h (1465W)	15	5
7000Btu/h (2051W)	15	5
9000Btu/h (2637W)	15	5
12000Btu/h (3516W)	20	10
18000Btu/h (5274W)	25	10

Cooling capacity	Max length of connection pipe	Max height difference	
24000Btu/h (7032W)	25	10	
28000Btu/h (8204W)	30	10	
36000Btu/h (10548W)	30	20	
42000Btu/h (12306W)	30	20	
48000Btu/h (14064W)	30	20	

- 4. The additional refrigerant oil and refrigerant charging required after prolonging connection pipe
  - After the length of connection pipe is prolonged for 10m at the basis of standard length, you should add 5ml of refrigerant oil for each additional 5m of connection pipe.
  - The calculation method of additional refrigerant charging amount (on the basis of liquid pipe):
    - Additional refrigerant charging amount = prolonged length of liquid pipe × additional refrigerant charging amount per meter
  - Basing on the length of standard pipe, add refrigerant according to the requirement as shown in the table. The additional refrigerant charging amount per meter is different according to the diameter of liquid pipe. See the following sheet.

# Configuration of connection pipe

Additional refrigerant charging amount for R22, R407C, R410A and R134a

Diameter of connection pipe		Outdoor unit throttle		
Liquid pipe(mm)	Gas pipe(mm)	Cooling only(g/m)	Cooling and heating(g/m)	
Ф6	Ф9.52 ог Ф12	15	20	
Ф6 ог Ф9.52	Ф16 or Ф19	15	50	
Ф12	Ф19 ог Ф22.2	30	120	
Ф16	Ф25.4 ог Ф31.8	60	120	
Ф19	-	250	250	
Ф22.2	_	350	350	


# Pipe expanding method

### Note:

Improper pipe expanding is the main cause of refrigerant leakage. Please expand the pipe according to the following steps:

A: Cut the pipe

- Confirm the pipe length according to the distance of indoor unit and outdoor unit.
- Cut the required pipe with pipe cutter.



B: Remove the burrs


 Remove the burrs with shaper and prevent the burrs from getting into the pipe.



C: Put on suitable insulating pipe


D: Put on the union nut

 Remove the union nut on the indoor connection pipe and outdoor valve; install the union nut on the pipe.



E: Expand the port

Expand the port with expander.



Note:


 "A" is different according to the diameter, please refer to the sheet below:

Outer diameter	A(mm)		
(mm)	Max	Min	
Ф6 - 6.35(1/4")	1.3	0.7	
Ф9.52(3/8")	1.6	1.0	
Ф12-12.7(1/2")	1.8	1.0	
Ф15.8-16(5/8")	2.4	2.2	

F: Inspection

Check the quality of expanding port.
 If there is any blemish, expand the port again according to the steps above.

smooth surface



the length is equal

Designed by Cooper&Hunter International Corporation, Oregon, USA www.cooperandhunter.com

E-mail: info@cooperandhunter.com



66160000078